
POST INSTALLATION INSTRUCTION:

- Dimensions of foundations as per Diag < A>.
- Leave post in sleeve when fitting to ensure all levels stay correct and keep post in place until concrete has "gone off" or sleeve may creep upwards as concrete dries.

GROUND SLEEVE INSTALLATION:



NOTE: Recommended foundation sizing only. Actual foundation depends on local ground conditions.

